

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
612RIU	AD009A0480		Orig	2/1/1982	Installation and Maintenance Manual	
6RW105YF1	GEI-72518		Orig	9/1/1958	Operating and Maintenance Instructions	
A100	0040-18001-01		D	4/3/2012	Installation Manual	
A-100						
IRIS						
AC-180A	TP-425	22-10-15	Orig	6/15/1989	Installation Manual	
ADC-4000	0040-30001-01		C	2/22/2017	Air Data Computer Installation Manual	
ADI-330A	TP-434	34-20-29	A	8/23/2017	Installation and Operation Manual	
ADI-330B						
ADI-330C						
ADI-330D						
ADI-330E						
ADI-330F						
ADI-330G						
ADI-330H						
ADI-330J						
ADI-330K						
ADI-330L						
ADI-330M						
ADI-330N						
ADI-330P						
ADI-330R						
ADI-330S						
ADI-330T						
ADI-330U						
ADI-330V						
ADI-330W						
ADI-330Y						
ADI-331A	TP-437		A	8/31/2003	Installation and Operation Manual	
ADI-331B						
ADI-331C						
ADI-331D						
ADI-331E						
ADI-331F						
ADI-331G						
ADI-331H						
ADI-331J						
ADI-331K						
ADI-331L						
ADI-331M						
ADI-331N						
ADI-331P						
ADI-332A	TP-458	34-20-40	Reis	3/19/1998	Installation and Operation Manual	
ADI-332B						
ADI-332C						
ADI-332D						
ADI-332E						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
ADI-333A ADI-333B	TP-445	34-20-67	A	12/23/2005	Installation and Operation Manual	
ADI-334A ADI-334B ADI-334C ADI-334D	TP-477	34-20-52	Reis	8/15/1994	Installation and Operation Manual	
ADI-335A ADI-335B ADI-335C ADI-335D ADI-335E ADI-335F ADI-335G ADI-335H ADI-335J ADI-335K ADI-335L ADI-335M ADI-335N ADI-335P ADI-335R ADI-335S ADI-335T ADI-335U	TP-490	34-20-49	C	11/24/2010	Installation and Operation Manual	
ADI-350BN	TP-532		B C1	8/30/2002	Installation and Operation Manual	
ADR-7050	0040-21453-01		L	1/6/2009	Installation Manual	
AI-330A AI-330AA AI-330AB AI-330AC AI-330AD AI-330AE AI-330AF AI-330AG AI-330AH AI-330AK AI-330AL AI-330AP AI-330AR AI-330AS AI-330AT AI-330AU AI-330AW AI-330AX AI-330AY AI-330AZ AI-330B AI-330BA	TP-454	34-20-51	C	2/5/2018	Installation and Operation Manual	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-330BB						
AI-330BC						
AI-330BE						
AI-330BH						
AI-330BJ						
AI-330BK						
AI-330C						
AI-330D						
AI-330E						
AI-330F						
AI-330G						
AI-330H						
AI-330J						
AI-330K						
AI-330L						
AI-330M						
AI-330N						
AI-330P						
AI-330R						
AI-330S						
AI-330T						
AI-330U						
AI-330V						
AI-330W						
AI-330X						
AI-330Y						
AI-330AF	TP-480	34-20-54	A	4/3/2018	Installation and Operation Manual	
AI-330AX						
AI-340B	TP-441	34-20-32	Reis	5/20/1995	Installation and Operation Manual	
AI-340C						
AI-350AD	TP-514	34-20-65	A	9/15/2004	Installation and Operation Manual	
AI-350R						
AI-350C	TP-596		A	12/19/2003	Installation and Operation Manual	
AI-350J	TP-507	34-20-63	Orig	10/31/1996	Installation and Operations Manual	
AI-350T	TP-595		A	12/19/2003	Installation and Operation Manual	
AI-360	TP-564		E	7/12/2007	Installation and Operation Manual	
AI-360()						
AI-360	TP-625		A	11/10/2006	Installation and Operation Manual	
AI-360()						
AI-803CK	TP-537		C	2/4/2016	Installation and Operation Manual	
AI-803CR	TP-516	35-20-66		7/26/2005	Installation and Operation Manual	
AI-803DA	TP-590		C	2/4/2016	Installation and Operation Manual	
AI-803DJ	TP-675		D	2/4/2016	AI-803DJ Install Manual	
AI-904AZ	TP-326	34-20-02	H	9/9/2013	Installation and Operation Manual	
AI-904W						
AI-804A						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-804AA						
AI-804AB						
AI-804AC						
AI-804AD						
AI-804AE						
AI-804AF						
AI-804AG						
AI-804AH						
AI-804AJ						
AI-804AK						
AI-804AL						
AI-804AN						
AI-804AR						
AI-804AS						
AI-804AU						
AI-804AV						
AI-804AW						
AI-804AX						
AI-804AY						
AI-804AZ						
AI-804B						
AI-804BA						
AI-804BB						
AI-804BC						
AI-804BE						
AI-804BF						
AI-804BG						
AI-804BJ						
AI-804BK						
AI-804BL						
AI-804BN						
AI-804BP						
AI-804BT						
AI-804BU						
AI-804BV						
AI-804BW						
AI-804BY						
AI-804C						
AI-804CA						
AI-804CC						
AI-804CE						
AI-804CF						
AI-804CH						
AI-804CJ						
AI-804CK						
AI-804CM						
AI-804CN						
AI-804CP						
AI-804CU						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-804CV						
AI-804D						
AI-804DA						
AI-804DB						
AI-804DC						
AI-804DD						
AI-804DE						
AI-804DF						
AI-804DG						
AI-804DH						
AI-804DJ						
AI-804DK						
AI-804DL						
AI-804E						
AI-804F						
AI-804G						
AI-804H/B						
AI-804H/G						
AI-804J/B						
AI-804J/G						
AI-804K						
AI-804L						
AI-804N						
AI-804P						
AI-804R						
AI-804S						
AI-804T						
AI-804U						
AI-804V						
AI-804W						
AI-804Y						
AI-804Z						
AI-904A/B						
AI-904A/G						
AI-904AA/B						
AI-904AA/G						
AI-904AB/B						
AI-904AB/G						
AI-904AC/B						
AI-904AD						
AI-904AE						
AI-904AF						
AI-904AH						
AI-904AJ						
AI-904AK/B						
AI-904AK/G						
AI-904AL						
AI-904AP						
AI-904AR						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-904AU						
AI-904AV						
AI-904AW						
AI-904AY						
AI-904B/B						
AI-904B/G						
AI-904C/B						
AI-904C/G						
AI-904D/B						
AI-904D/G						
AI-904E/B						
AI-904E/G						
AI-904F/B						
AI-904F/G						
AI-904G/G						
AI-904H/B						
AI-904H/G						
AI-904HA/B						
AI-904HA/G						
AI-904HB/B						
AI-904HB/G						
AI-904HC/B						
AI-904HC/G						
AI-904HD/B						
AI-904HD/G						
AI-904J/B						
AI-904K/B						
AI-904L/B						
AI-904M/B						
AI-904M/G						
AI-904N/B						
AI-904N/G						
AI-904P/B						
AI-904P/G						
AI-904R/B						
AI-904R/G						
AI-904S/B						
AI-904S/G						
AI-904S/HB/B						
AI-904S/HB/G						
AI-904T/B						
AI-904T/G						
AI-904U/B						
AI-904U/G						
AI-904U/HA/B						
AI-904U/HA/G						
AI-904U/HC/B						
AI-904U/HC/G						
AI-904V/B						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
AI-904V/G AI-904Y/B AI-904Y/G AI-904Z/B AI-904Z/G						
AI-804CD	TP-599		C	2/4/2016	Installation and Operation	
SPS-340A SPS-341A SPS-341B SPS-341C SPS-360A SPS-360B SPS-360C SPS-360D SPS-380A SPS-380B SPS-380C SPS-380D SPS-380E SPS-600C SPS-600D SPS-600E	TP-520	27-30-10	C	8/16/2010	Installation Manual	
AN/ARN-154(V)	009-10062-001		L	9/26/2018	Installation Manual	
ANI7000	12710138B		B	3/1/1987	Installation Manual	
BC-815A	TP-350		B	6/28/2010	Installation Instructions	
AN/ARN-154(V) BTP-1634	009-10140-001		B	11/13/2003	Instruction Manual	
CD800	009-11800-001		A C1	11/6/2000	Instruction Manual	
9080-17250-02 9080-17250-12 CP-2500	0040-17251-01 NOW ACSS		A	9/14/2018	Control Panel for ADS-B UAT Device	
CR2795E100A1	GEI-36528B		B	10/1/1969	Instructions	
CA-2001A/B CA-2001A/G CA-2001B/B CA-2001B/G CA-2001C/B CD-2001A/B CD-2001A/G CD-2001B/B CD-2001B/G CD-2001C/B CD-2001C/G DAC-2000 DC-2001A DC-2001B DC-2001C	TP-258		Orig	8/1/1980	Instruction Manual, Operation and Installation	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
DC-2001D						
DC-2001E						
DC-2001F						
DC-2001G						
DC-2001H						
DC-2001K						
FC-2001A/B						
FC-2001A/G						
FC-2001B/G						
FC-2001C/B						
FC-2001C/G						
FC-2001D/B						
FC-2001D/G						
OC-2001A/B						
OC-2001A/G						
OC-2001B/B						
OC-2001B/G						
OC-2001C/B						
OC-2001C/G						
PS-2001A						
PS-2001B						
RC-2001A						
RC-2001B						
DB682	009-10099-001		Orig	12/8/1995	Installation Manual	
DB683	009A0652		2	10/9/1995	Installation Manual	
DG-710B	TP-586		B	12/3/2003	Installation and Operation Manual	
DGS-710A	TP-429	34-20-26	Orig	12/1/1989	Installation Manual	
DGS-710B						
DME670	009A0601		Orig	1/1/1986	Installation Manual	
DME675	009A0305		C1	12/1/1990	Installation Manual	
TX675						
DU-42	0040-38501-01		D	6/2/2016	DU-42 Installation Manual	
EBDI-4000	TP-566		C	1/31/2018	Installation and Operation Manual	
EHSI-4000	TP-580		B	12/6/2007	Installation and Operation Manual	
ESI-1000	0040-32001-01		U	10/13/2017	ESI-1000 Installation Manual	
ESI-2000	0040-32501-01		L	8/1/2018	ESI-2000 Installation Manual	Electronic Standby System with Battery Backup
ESI-500	0040-15001-01		G	2/27/2018	ESI-500 /MAG-500 Installation Manual	
MAG-500						
ESIS-5000	0040-43001-01		D	2/27/2017	Electronic Standby Instrument System with Touch Screen	
LRN500	009A0631A		4	4/1/1989	Installation Manual	
A150	165E1846-00		19	8/4/2015	FA2100CVR Install Manual	
A151B						
A152B						

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
A55B FA2100 S055 S056 S058 S150 S151 S152 S160 S161 S162 S251 S261						
FA2100 FDR FDR	165E1845-00		09	7/1/2015	FA2100 FDR Install Manual	
ADC-3000 DCM-3000 GH-3000 MAG-3000	TP-579		E	5/1/2018	Installation and Operation Manual	
ADC-3000 DCM-3000 GH-3000AA GH-3000AB GH-3000AC GH-3000AD GH-3000AE GH-3000J GH-3000K GH-3000L GH-3000M GH-3000N GH-3000P GH-3000R GH-3000T GH-3000V GH-3000W GH-3000Y MAG-3000	TP-531		C	5/27/2009	Installation and Operation Manual	
GH-3000 GH-3000AF GH-3000AG GH-3000AH GH-3000AJ GH-3000AK GH-3000AL GH-3000AM GH-3000AN GH-3000AP	TP-546		T	3/30/2017	Installation and Operation Manual	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description						
GH-3000AR GH-3000AT GH-3000AU GH-3000AV GH-3000AW GH-3000AY GH-3000BA	TP-503	34-20-57	A	5/27/2009	Installation and Operations Manual							
GH-3000A GH-3000B GH-3000C GH-3000D GH-3000E GH-3000F GH-3000G GH-3000H												
GH-3000D							TP-511	34-20-60	4/29/1996	Installation and Operation		
ADC-3000 DCM-3000							TP-593		12/18/2013	Installation and Operation Manual		
GH-3001 MAG-3000							TP-530		L	6/15/2016	Installation and Operation Manual	
ADC-3000 DCM-3000 GH-3001 MAG-3000												
DCM-3100 GH-3100 GH-3100 (2.1 software) GH-3100 (2.X Software) GH-3100 (4.X Software) MAG-3000												
DCM-3100 GH-3100 MAG-3100							TP-582		G	3/4/2010	Installation and Operation Manual	
GH-3100							TP-559		K	3/30/2017	Installation and Operation Manual	
GH-3100							TP-629		B	3/4/2010	GH-3100 Instalation & Operation Manual (-0205)	
GH-3900 SHIS-3900	0040-34001-01		R	6/26/2017	GH-3900 (SFIS-3900) Install Manual							
GH-3900.2 KC-390	0040-34701-01		A	2/22/2017	GH-3900.2 Opertion Manaul for KC-390							
GH-3900.2	0040-34401-01		R	8/31/2018	0040-34400-01	Electronic Standby Instrument System						
GH-3900RSU	0040-38001-01		D	6/2/2016	GH-3900RSU Install Manual							
GH-4001	0040-45001-01		E	8/23/2016	GH-4001 Install Manual							
GH-4001	0040-45101-01		A	3/23/2017	GH-4001 Installation & Operation Manual							

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
DU-38/A GH-4200	0040-42000-01		E	3/16/2015		
9200-42000-020 1	0040-42001-01		E	3/16/2015	Electronic Standby Instrument System	
9200-42600-020 1						
DU-38/A DU-39/A GH-4200 GHR-4000						
HSI-3000	TP-597		0	3/17/2004	Installation and Operation Manual	
HSI-3000	TP-570		F	7/17/2017	Installation and Operation Manual	
i-linc	0040-19000-01		J	2/3/2009	Installation Manual	
JT-113A	TP-409			7/26/2005	Installation Manual	
LNS6000	009-10001-001		B	3/10/1997	Installation Manual	
LA120 LNS616 LR651 NY151 RNC601	009A0551B		0	11/1/1983	Installation Manual	
MAG-3000	TP-633		L	1/29/2018	MAG-3000 Installation Manual	
MAG-3100	0040-21200-01		J	9/5/2017	MAG-3100 Installation Manual	
LYNX NGT-1000 NGT-2000 NGT-2500	0040-17011-01 NOW ACSS		A	9/14/2018	Installation Manual	
LYNX NGT NGT 9000 NGT9000 NGT-9000 NGT-9000+ NGT-9000D NGT-9000D+ NGT-9000R NGT-9000R+ NGT-9000RD NGT-9000RD+	0040-17001-01 NOW ACSS		A	9/14/2018	Installation Manual	MultiLink Surveillance System
PL-103A PL-103B	TP-374	24-50-04	Reis	12/15/1992	Installation Manual	
PS-823A PS-823A/T PS-823B PS-823B/T PS-823C PS-823C/T	TP-352		Orig	6/10/1987	Installation instructions	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
PS-823D PS-823D/T PS-823E PS-823E/T PS-823F PS-823F/T PS-823G PS-823G/T PS-823H PS-823H/T						
PS-834A PS-834B	TP-447	24-30-05	B	5/8/2006	Installation and Operation Manual	
PS-835A PS-835B PS-835C PS-835D PS-835E PS-835F PS-835G	TP-336	24-30-04	P	3/20/2017	Installation Manual	
PS-850A PS-850B PS-855A PS-855B PS-855C PS-855D	TP-470	24-30-07	K	8/22/2017	Installation and Operation Manual	
RGC250	009-11400-001		A C4	7/27/2000	Installation Manual	
RGC250 (enhanced interface)	009-11407-001		A	3/14/2002	Installation Manual	
RGC350	009-12400-001		A	6/25/2002	Installation Manual	
SA-151D	TP-432	22-10-17	Reis	2/28/1998	Installation Manual	
SC-841A	TP-351		A	4/5/2007	Installation Instructions	
SCD526	009-10084-001		Orig	9/16/1994	Instruction Manual	
SHSI-3000	TP-600		C	8/2/2011	Installation and Operation Manual	
SI-1000A SI-1000B SI-1000C SI-1000G SI-1000K SI-1250A SI-1500A SI-1500L SI-2500A SI-2500B SI-2500BP SI-2500LP SI-3000A	TP-540		F	7/22/2014	Installation and Operation Manual	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
SI-3000B SI-3003B SI-3003C						
SI-100A SI-100B	TP-346		A	4/13/2007	Installation Instructions	
SI-3000A	TP-249			7/26/2005	Installation and Operation Manual	
SI-3003B	TP-310		A	8/18/2011	Installation Manual	
SI-3003C	TP-469	24-20-15	A	8/18/2011	TP-469	
SIM-3100	TP-619		A	5/22/2006	Installation and Operation Manual	
SIM-3100	TP-632		A	12/9/2009	TP-632	
SPS-341D	TP-634	27-30-13	C	8/28/2013	SPS-341D Installation Manual	
TAWS8000	009-18001-001		G	7/28/2011	Installation Manual	
TAWS8100	009-18651-001		F	8/23/2017	Installation Manual	
TCAS791 TCAS-791 TCAS-791A	009-10013-001		H	7/18/2013	Installation Manual	
F3849 F6344 F6444 F6555 IN602 TCN970 TX970	009A0301		1	8/1/1988	Installation Manual	
TRC2634 TRC-2634	0040-35001-01		J	1/9/2019	Tacan+ Installation Manual	Tactical Air Navigation System
TSC-1000	0040-44004-01		A	5/1/2018	Remove and Replace Instructions	
TSC-1000	0040-44001-01		C	5/1/2018	TSC-1000 Install Manual	
VG-204AB	TP-363		Reis	3/10/1986	Installation instructions	
VG-204AC VG-204AU VG-204D VG-204L	TP-594		B	11/7/2003	Installation Manual	
VG-204AM	TP-487	34-20-47	Orig	5/11/1994	Installation and Operation Manual	
VG-206C	TP-226		Orig	11/8/1974	Installation Instructions	
VG-206D	TP-424	34-20-08	Orig	6/15/1989	Installation Manual	
VG-208A VG-208B VG-208C	TP-270		B	9/4/2012	Installation Manual	
VRS-3000	TP-561		P	10/18/2016	Installation Manual	
VRS-3010 VRS-3020	TP-592		F	10/28/2016	Installation Manual	
VRS-4000	TP-598		E	4/28/2015	Installation Manual	
WX-1000 WX-1000+	78-8060-5815-8		D	9/30/2005	Checklist Worksheet	

Install Manual Index

Last Updated: 1/14/2019 10:58:16 AM

Aviation Products
L3 Technologies
5353 52nd St. SE
Grand Rapids, MI 49512

Model Number	Publication Number	ATA Number	Revision Level	Revision Date	Manual Description	Product Description
WX-1000 WX-1000+ WX-1000E	78-8051-9150-5		H	1/9/2017	Installation Manual	
WX-500	009-11500-001		L	11/8/2017	Installation Manual	
WX-7A	377A200		2	1/1/1980	Installation and Technical Manual	
WX-10 WX-10A WX-11 WX-12 WX-8 WX-9	78-8041-7921-2		Orig	7/1/1985	Installation Manual	
WX-900	78-8060-6104-6		D	11/20/2001	Installation Manual	
WX-950	009-10950-001		E	3/7/2017	Installation Manual	
WX-950G	009-10959-001		A	4/22/2009	WX-950G Installation and Operation Manual	
WX-PA	78-8060-5798-6		E	7/23/2014	Instruction Manual	
WX-SM	78-8060-5874-5		G	11/11/2003	Instruction Manual	